
Getting started with the 24 V Intelligent Power Switch expansion board based on VPS2535H for STM32 Nucleo

Introduction

The X-NUCLEO-IPS02A1 is a 24 V Intelligent Power Switch expansion board based on the VPS2535H for STM32 Nucleo, a double channel high-side driver made using STMicroelectronics® VIPower technology.

X-NUCLEO-IPS02A1 provides a low cost, robust and easy-to-use solution for driving grounded loads, i.e. relay replacement, heating elements, solenoid driver, LED driver, light bulb driver, pumps and fans, in STM32 Nucleo projects.

The X-NUCLEO-IPS02A1 is compatible with the Arduino™ UNO R3 connector, and supports the addition of other expansion boards with a single STM32 Nucleo board. The user can also solder the ST morpho connectors.

In the boards some test points allow the user to check and measure both analog and digital signals.

Two red LEDs show the output status; a green LED shows if the board is supplied properly.

Two X-NUCLEO-IPS02A1 boards can be plugged to drive up to 4 loads with a single STM32 Nucleo board.

Contents

- 1 Getting started 5**
- 2 Hardware and software requirements 7**
- 3 Hardware description and configuration 8**
 - 3.1 Jumpers configurations11
 - 3.2 Multi expansion board configuration11
- 4 Current sense configuration 13**
 - 4.1 Introduction 13
 - 4.2 RSense and voltage divider design 14
- 5 Board schematics 15**
- 6 PCB Layout 16**
- 7 BOM 17**
- 8 Revision history 19**



List of tables

Table 1.	Operative ratings of the X-NUCLEO-IPS02A board	5
Table 2.	Arduino UNO R3 connector table	9
Table 3.	ST morpho connector table	10
Table 4.	Jumpers configurations.	11
Table 5.	Jumpers configurations.	11
Table 6.	BOM List.	17
Table 7.	Document revision history	19

List of figures

Figure 1.	Connectors position	8
Figure 2.	Jumpers position.	9
Figure 3.	HSD current sense circuit.	13
Figure 4.	Board schematic (part 1)	15
Figure 5.	Board schematic (part 2)	15
Figure 6.	Top Layout	16
Figure 7.	Bottom Layout.	16

1 Getting started

The X-NUCLEO-IPS02A1 is a 24 V double channel Intelligent Power Switch expansion board for STM32 Nucleo, able to provide an affordable and easy-to-use solution for driving grounded loads as:

- heating elements
- relay replacements
- solenoid drivers
- LED drivers
- light bulb drivers
- pumps and fans

Up to two X-NUCLEO-IPS02A1 can be plugged on the same STM32 Nucleo board as scribed in [Section 3.2: Multi expansion board configuration](#).

Table 1. Operative ratings of the X-NUCLEO-IPS02A board

		Min	Nom	Max
Operating Voltage range from		8 V	24 V	36 V
Undervoltage Shutdown			3.5 V	5 V
Overvoltage Shutdown Hysteresis			500 mV	
Current limitation		30 A	42 A	55 A
On-state resistance (per Ch)	25 °C		35 mΩ	
	150 °C			70 mΩ
Temparture Range		-40 °C		150 °C

The device VPS2535H integrates advanced protective functions and the load current limitation protects the device against overload conditions. The device latches off in case of overload or thermal shutdown.

VPS2535H is intended for driving resistive or inductive loads with one side connected to ground. VPS2535H integrates an analog current sense circuit for each output channels, which delivers a current proportional to the load current. The digital inputs are 3 V and 5 V CMOS compatible.

Follow this sequence to start your project with the board:

1. Check and configure the 0R or jumpers setting based on your configuration (see Section [Section 2: Hardware and software requirements](#)).
2. Plug the board to the STM32 Nucleo board through Arduino UNO R3 connector for the X-NUCLEO-IPS02A1.
3. Connect the PSU to J1 connector: 1-VBatt, 2-GND. The wires size must be appropriately selected to avoid excessive voltage drops and overheating when the board operates continuously under full load.
4. Supply the board; the LED1 (green) will be turned on
5. Develop your application using the examples provided with the firmware library, X-NUCLEO-IPS02A1, 24V Multi-purpose Dual channel Smart Power High Side Driver software expansion for STM32Cube.

Further support material is available on the VPS2535H and STM32 Nucleo web pages on www.st.com.

2 Hardware and software requirements

Using the STM32 Nucleo boards with the X-NUCLEO-IPS02A1 expansion board requires the following software and hardware:

- 1 x Windows PC to install the software package.
- One X-NUCLEO-IPS02A1 expansion board.
- A STM32 Nucleo board (i.e. NUCLEO-L0538, NUCLEO-F401RE).
- 1 x USB type A to Mini-B USB cable to connect the STM32 Nucleo board to the PC.
- The X-CUBE-IPS02 software package (available on www.st.com).
- 1 x external power supply able to provide the right voltage and the current capability to supply the loads.
- (optional) a terminal emulator, serial console (i.e. PuTTY) to read data via USART.

3 Hardware description and configuration

Figure 1 and Figure 2 show the position of the connectors and the jumpers respectively present in the board.

Figure 1. Connectors position





Figure 2. Jumpers position



Below are the pinout details for the Arduino UNO R3 and the ST morpho connectors

Table 2. Arduino UNO R3 connector table

Connector	Pin ⁽¹⁾	Signal	Remarks
CN5	1 (D8)	FR_Stby (option)	Option Configuration See Section 3.1: Jumpers configurations
	2 (D9)	IN 1 (option)	
	3 (D10)	IN 2 (option)	
CN9	5 (D4)	FR_Stby (Default)	Option Configuration See Section 3.1: Jumpers configurations
	6 (D5)	IN 1 (Default)	
	7 (D6)	IN 2 (Default)	
CN6	2	+3V3	
	5	+5V	
	6, 7	GND	

Table 2. Arduino UNO R3 connector table (continued)

Connector	Pin ⁽¹⁾	Signal	Remarks
CN8	1 (A0)	Multisense_1 (Option)	See Section 3.1: Jumpers configurations
	2 (A1)	Multisense_2 (Option)	
	3 (A2)	Multisense_1 (Default) GND_Sense (Option)	
	4 (A2)	Multisense_2 (Default)	
5 (A4)	GND_Sense (Option)		

1. All the unlisted pins are not connected

Table 3. ST morpho connector table

Connector	Pin	Signal	Remarks
CN7	12 16	+3 V 3	See Section 3.1: Jumpers configurations
	14	NRST	
	18	+5 V	
	8 19 20 22	GND	
	28	Multisense_1 (option)	
	30	Multisense_2 (option)	
	32	Multisense_1 (default) GND_Sense (option)	
	34	Multisense_2 (default)	
	36	GND_Sense (option)	
	CN10	9 20 32	
17		IN 2 (option)	
19		IN 1 (option)	
21		FR_Stby (option)	
25		IN 2 (default)	
27		IN 1 (default)	
29		FR_Stby (default)	

3.1 Jumpers configurations

Various board configurations are possible, depending on the use cases.

The hardware configuration can be modified via the appropriate setting the R12 to R24 0R resistors as indicated [Table 4](#).

Table 4. Jumpers configurations

	Default configuration	Option configuration
R12	Not mounted	Not mounted
R13	0 Ω	Not mounted
R14	0 Ω	Not mounted
R15	Not mounted	0 Ω
R16	Not mounted	0 Ω
R17	Not mounted	Not mounted
R18	Not mounted	0 Ω
R19	Not mounted	0 Ω
R20	Not mounted	0 Ω
R21	0 Ω	Not mounted
R22	0 Ω	Not mounted
R23	0 Ω	Not mounted
R24	Not mounted	Not mounted

3.2 Multi expansion board configuration

Two X-NUCLEO-IPS02A1 expansion boards can be plugged on a single STM32 Nucleo board in order to drive up to the 4 loads (one expansion board for two loads is required).

The 0R jumpers present in the boards must be set as described in [Table 5](#).

Table 5. Jumpers configurations

	Board #1 ⁽¹⁾	Board #2
R12	Not mounted	Not mounted
R13	0 Ω	Not mounted
R14	0 Ω	Not mounted
R15	Not mounted	0 Ω
R16	Not mounted	0 Ω
R17	Not mounted	Not mounted
R18	Not mounted	0 Ω
R19	Not mounted	0 Ω
R20	Not mounted	0 Ω

Table 5. Jumpers configurations (continued)

	Board #1 ⁽¹⁾	Board #2
R21	0 Ω	Not mounted
R22	0 Ω	Not mounted
R23	0 Ω	Not mounted

1. This is the default configuration.

Note: If two identical boards are plugged, pay attention to avoid shortcut between the terminal blocks and to avoid shortcut between the wires connected to the two boards.

4 Current sense configuration


4.1 Introduction

The current sense feature allows measure a voltage signal that is proportional to the load current across an external resistor R_{sense} .

Figure 3 shows the topology implemented in the HSD current sense circuit.

The principle of operation is to compare the currents flowing through two paths: the sense path made up of the series of a Sense-MOSFET plus the R_{sense} (I_{sense}) and the power path made up of the series of Power-MOSFET plus the load (I_{out}).

Figure 3. HSD current sense circuit



The op-amp compares the voltage drop due to the load current ($V_{DS_Power} = R_{DSon_Power} \cdot I_{OUT}$) to the voltage drop across the Sense-MOSFET ($V_{DS_Sense} = R_{DSon_Sense} \cdot I_{sense}$). During the normal working condition in on state is: $V_{DS_Sense} = V_{DS_Power}$, and therefore:

Equation 1

$$R_{DSPOWER} \cdot I_{LOAD} = R_{DSSENSE} \cdot I_{SENSE}$$

Since:

Equation 2

$$V_{SENSE} = R_{DSSENSE} \cdot I_{SENSE}$$

The K parameter is defined as:

Equation 3

$$K = \frac{R_{DS_{SENSE}}}{R_{DS_{POWER}}}$$

And the V_{sense} expression is:

Equation 4

$$V_{SENSE} = \frac{R_{DS_{SENSE}} \cdot I_{LOAD}}{K}$$

4.2 R_{sense} and voltage divider design

R_{sense} and the voltage divider resistors (see R3-R4 and R7-R8 in [Figure 5](#)) must be selected considering the maximum output current^(a) and the maximum V_{Sense} levels.

Multsense1 and Multsense2 signals are measured by using an ADC and under any working condition, the ADC input stage must not be saturated.

The default configuration of the X-NUCLEO-IPS02A is assembled with these components:

- R_{sense} : 1 k Ω
- R3 = 56 k Ω
- R4 = 36 k Ω

The voltage divider ratio defined by the [Equation 5](#): is "0.39":

Equation 5

$$\text{Voltage}''''\text{Diver}''''\text{Ratio} = \frac{R_4}{R_3 + R_4}$$

The attenuation introduced by the voltage divider avoids the ADC input stage also when $V_{Sense} = V_{SenseMax}$.

To measure the load current reading the Multsense1 and Multsense2 voltage levels, the attenuation due to the voltage divider must be considered in the computation. In detail, the Multsense1 and Multsense2 voltage levels must be multiplied by a factor ($1/VolatgeDivideRatio$); in this specific situation, the multiplier factor is 2.55.

a. In the maximum current level, the overshoot and transition must be considered.

5 Board schematics

Figure 4. Board schematic (part 1)





Figure 5. Board schematic (part 2)



6 PCB Layout

Figure 6. Top Layout





Figure 7. Bottom Layout



7 BOM

Table 6. BOM List

Quantity	Comment	Designator	Footprint	Assembly Option
1	100nF	C1	0805_C	
2	10nF	C2, C3	0805_C	
2	1nF	Cext1, Cext2	0805_C	
1	Header 10X1_M-F	CN5	SIP10 Male-Female	
2	Header 8X1_M-F	CN6, CN9	SIP8 Male-Female	
2	Header 19X2	CN7, CN10	SIP38 Female	
1	Header 6X1_M-F	CN8	SIP6 Male-Female	
1	STTH1L06	D1	SMA	Not Assembled
1	VBatt	J1	Terminal Block 2 POS	
1	Output	J2	Terminal Block 2 POS	
1	LED2_green	LED 1	0805_LED	
2	LED2_red	LED 2, LED 3	0805_LED	
3	2K2	R1, R9, R10	0805_R	
5	56K	R2, R3, R5, R6, R7	0805_R	
2	36K	R4, R8	0805_R	
6	0R	R11, R13, R14, R21, R22, R23	0805_R	
7	0R	R12, R15, R17, R18, R19, R20, R24	0805_R	Not Assembled
1	0R	R16	0805_R	Not Assembled
2	1k	Rsense1, Rsense2	0805_R	
2	---	R_UP1, R_UP2	0805_R	Not Assembled
1	GND	TP1	TPoint	
1	V_Batt	TP2	TPoint	
1	IN0	TP3	TPoint	
1	CS1	TP4	TPoint	
1	IN1	TP5	TPoint	
1	CS2	TP6	TPoint	
1	FR_Stby	TP7	TPoint	
1	MultiSense1	TP8	TPoint	
1	GND_Sense	TP9	TPoint	

Table 6. BOM List (continued)

Quantity	Comment	Designator	Footprint	Assembly Option
1	MultiSense2	TP10	TPoint	
1	VPS2535H	U1	PSS024	

8 Revision history

Table 7. Document revision history

Date	Revision	Changes
21-Jun-2016	1	Initial release.

IMPORTANT NOTICE – PLEASE READ CAREFULLY

STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST's terms and conditions of sale in place at the time of order acknowledgement.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of Purchasers' products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2016 STMicroelectronics – All rights reserved